Module SC15

Scotland Route Sectional Appendix Module 15



This page is intentially blank

LIST OF MODULE PAGES AND DATES


Page	Date Last Changed
1	02 December 2006
2	02 December 2006
3	02 December 2006
4	02 December 2006
5	02 December 2006
6	02 December 2006
7	02 December 2006
8	02 December 2006
9	02 December 2006
10	02 December 2006
11	02 December 2006
12	02 December 2006
13	02 December 2006
14	02 December 2006
15	02 December 2006
16	02 December 2006
17	02 December 2006
18	02 December 2006
19	02 December 2006
20	02 December 2006
21	02 December 2006
22	02 December 2006
23	02 December 2006
24	02 December 2006
25	02 December 2006
26	02 December 2006
27	02 December 2006
28	02 December 2006
29	02 December 2006
30	02 December 2006
31	02 December 2006
32	02 December 2006
33	02 December 2006
34	02 December 2006

Page	Date Last Changed
35	02 December 2006
36	02 December 2006
37	02 December 2006
38	02 December 2006
39	02 December 2006
40	02 December 2006
41	02 December 2006
42	02 December 2006
43	02 December 2006
44	02 December 2006
45	02 December 2006
46	02 December 2006
47	02 December 2006
48	02 December 2006
49	02 December 2006
50	02 December 2006
51	02 December 2006
52	02 December 2006
53	02 December 2006
54	02 December 2006
55	02 December 2006
56	02 December 2006
57	02 December 2006
58	02 December 2006
59	02 December 2006
60	02 December 2006
61	02 December 2006
62	02 December 2006
63	02 December 2006
64	02 December 2006
65	02 December 2006
66	02 December 2006

TABLE OF CONTENTS

	raye
Maps	3
Table A Diagrams	5
Special Working Arrangement	49
Route Clearance	51
Local Instructions	53

MAPS






This page is intentially blank

TABLE A DIAGRAM Table of Contents

Pag
6
37
47



LOR Seq. Line of Route	Description			ELR	Route	Last Updated	
SC203 002 Inverness to				WCK	Scotland 02/12/0		
Location	Mileage M Ch	Running lines &	speed restrictions		Signalling & Remarks		
		15X TRAINS ONLY UN DN 25 25	OTHER THAN 15X T UN DN 25 25	RAINS	TCB Inverne UN = Up North DN = Down North	ss SC (I)	
	0 41 * 0 46 *		25 25 50 *		Lines between the top of the page and Clachnahamy Do Stop Signal (Down direction Signal 430 (Up direction) are controlled by Inverness (TCB) SC (I)	wn n)∕	
Signal I430	0 47	ļ.	20 50		RETB 102		
Clachnaharry Down Stop Signal	0 60 *	50	 - - 		RETB controlled by Inverni (RETB) SC applies betwee Clachnaharry Down Stop S (Down direction)/Signal I43	n Signal 60	
Clechnaharry Canal Bridge	1 45 * 1 46	10	10		(Up direction) and the end the page	of	
	1 50 *:	* 	* [65]				

LOR Seq. Line of Rout				ELR	Route	Last Update
SC203 003 Inverness to				wck	Scotland	02/12/06
Location	Mileage M Ch	Running	lines & speed restrictions		Signatling &	Remarks
		15X TRAINS ONLY	OTHER THAN 15X TR	AINS	RETB 102 Inverse	ess SC (I)
Bruichnain LC (UWC)	2 63		I T			
Bullocks LC (UWC)	2 73 T		<u> </u>			
Bunchrew Farm LC (UWC)	3 10					
Bunchrew LC (AOCL)	3 58 5 01 *	45 ▼	▲30 50			
Lentran Station LC (UWC)	5 64 T	75	* * * * * * * * * *			
	6 47 (1)	1 ①	•		(1) = 50mph over UB 25	
Groam Farm South LC (UWC)	7 29 T					
Groam Farm LC (UWC)	7 41 T		<u> </u>			
Clunes TEP	7 51 <u>T</u>	<u>‡</u>	<u> </u>			
		75	65			

LOR	Seq.	Line	of Route	Descr	iptio	1					ELR	Ro	ute	Last Updated
SC203	004	Inve	erness to	Wick							WCK	Scot	land	02/12/06
	Loc	atior	1	M	ileag C	e Ch		Runnir	ng lines & spe	ed restrictions		Sig	nalling &	Remarks
						i	·	15X TRAINS ONLY		OTHER THAN 1	15X TRAINS	RETB 102	Inverne	ess SC (I)
								75		65		i:		
					8 75	*		*						
Beauly Fe	rry LC (l	JWC)			9 29		[<u>T</u>]		T					
					9 36			65						
BEAULY					10 12									
				1	10 61	*) *		55 				
					11 00	*		75						
Wellhouse	LC (UV	VC)			11 10		T		I					
								75		65				
								13		<u></u>				

LOR	Seq.	Line of	Route D	escription					ELR	Rou	ite	Last Updated
SC203	005	Inverne	ess to Wi						WCK	Scotla	and	02/12/06
	Loc	ation		Mileage M Ch		Running li	nes & speed	restrictions		Signalling & Rem		temarks
Sdgs GF's		rep		13 04	15X TI		©; ∃ Dn Sdgs	OTHER THAN 1	5X TRAINS	RETB 102 1530f (466m) (73 SLU's) RETB 105	Invernes	SC (I)
Chapleton	LC (UW	(C)		13 53	; (1)	<u> </u>	T	1		① = 15mph throu points, in bo and over loc	oth directions,	
Keepers H	louse LC	(UWC)		15 54	T		T					
Riverford I	.c (UW(C)		16 14	T		T					
						75	**************************************	65				

LOR Seq. Line of Rou	te Description			Route	Last Update		
SC203 006 Inverness to	o Wick	WCK	Scotland	02/12/06			
Location	Mileage M Ch		ines & speed restrictions	Signalling & I	Signalling & Remarks		
	16 53 *	15X TRAINS ONLY 75	OTHER THAN 15X TRAINS 65	RETB 102 Invernes	ss SC (I)		
Maryburgh LC (UWC) Kildun No 1 LC (UWC)	17 15 T	. <u> </u> .	<u>.T</u>	1 = 15 mph through loop points, in both direction and over loop lines	s,		
Pitglassie South LC (UWC)	18 10 T	75	T	DRS 1075f (325m) (52 SLU's)			
Pitglassie Field LC (UWC) Pitglassie North LC (UWC)	18 23 T	DRS	TDRS	CL 1345f (410m) (65 SLU's) 2) Permissive arrangements RETB territory.	in		
Sdg GF	(S)	5 PP(A) 2	5 PP(A).2:	PP(A) - detaching, for booke movements only See Local Instructions for conditions under which trains			
DINGWALL TEP	18 58 T	PP(A):2) ¥	PP(A)(2) \(\frac{1}{2} \)	detach Plungers are provided at the Down "Points Sel" indicators for operating the junction points under the instructions of the signaller at Inverness	3		
	18 76 *	45 To Kyle I SC205 se	40 To Kyle SC205 seq 1	(RETB) SC. A duplicate plunger, for the Down line only, is additionally provided on the Down platform under the overbridge			

LOR Seq. Line of Route				ELR	Rou		Last Update
SC203 007 Inverness to	Wick			WCK	Scot		02/12/06
Location	Mileage M Ch	Running l	lines & speed restrictions		Sig	nalling & Re	emarks
	:	15X TRAINS ONLY	OTHER THAN 15	X TRAINS	RETB 102	Inverness	SC (I)
		65	65				
	:						
Dingwall Canal North LC (UWC)	19 03 T		T				
	20 00 *	; 					
	į	75					
	22 18 *	 * ▼					
		▲ `75 65 ▼	65 				
	22 75 *	* *					
		 65 					
Foulis LC (R/G)	22 76	. 					
	22 77 *	. 					
		▲ 65	65				

LOR Seq. Line of Route	Description			ELR	Rout	te Last Updated	
SC203 008 Inverness to V				WCK	Scotla	and 02/12/06	
Location	Mileage M Ch	Running I	ines & speed restrictions		Signalling & Remarks		
	:	15X TRAINS ONLY	OTHER THAN 15	SX TRAINS	RETB 102	Inverness SC (I)	
		▲65 75▼	65				
Ballachladdich Farm LC (UWC)	23 15 T		T				
	23 54 *	A ‡					
		75	65				
Evanton TEP	25 00 T	‡	 				
	27 73 *	*	*				
		 60	 50 				
	28 33 *	! * !					
ALNESS	28 70						
	A 6	70	`65				

LOR Seq. Line of Rou			ELR	Route	Last Update
SC203 009 Inverness to			WCK	Scotland	02/12/06
Location	Mileage M Ch	Running I	ines & speed restrictions	Signalling &	Remarks
	28 73 *	15X TRAINS ONLY	OTHER THAN 15X TRAINS 65	RETB 102 Inven	ess SC (I)
Belleport LC (UWC)	29 28 T	75	T		
	30 50 ★	* 60 	* 		
South and loop points	31 16 * (\$)	5 1		1) = 15 mph through loop points, in both directic and over loop lines	ins,
INVERGORDON TEP	31 37 T		T	CL 1305f (395m) (63 SLU's)	
North end loop points	31 50 *	0 *	①* 65		

14

December 2006

LOR Seq. Line of Route D				ELR	Route	Last Updated	
SC203 010 Inverness to W			WCI	К	Scotland	02/12/06	
Location	Mileage M Ch	Running lii	nes & speed restrictions		Signalling & Remarks		
		15X TRAINS ONLY	OTHER THAN 15X TRAINS	RETE	3 102 Inverne	ess SC (I)	
		65	65				
Distillery No 1 GF	31 76 (S)	□ 1,1 3,5 5	©				
Distillery No 2 GF	32 07 (S)	5	§ 5				
	32 15 *	 					
Invergordon Distillery LC ④	32 20			①=	= Crossing Attendant proby Distillery	rovided	
		75	65				

		Description		ELR	Route Last Updated
SC203 011	Inverness to	Wick		WCK	Scotland 02/12/06
Loca	ition	Mileage M Ch	Running lin	es & speed restrictions	Signalling & Remarks
			15X TRAINS ONLY	OTHER THAN 15X TRAINS	RETB 101 Inverness SC (I)
Balintraid LC (UWC	;)	33 50 T	*****	T	
		34 45 *	* ♥ ^75 65 ♥		
			65 		
Deiny LC (AOCL)		34 79	55 ▼	30 ▼ 55 ▼	
			65	65	

LOR Seq. Line of Rou	ute Description			ELR	Rout	е	Last Updated
SC203 012 Inverness t	to Wick			WCK	Scotla	nd	02/12/06
Location	Mileage M Ch	Running lines	& speed restrictions		Signalling & Remarks		
		15X TRAINS ONLY	OTHER THAN 15X TI	RAINS	RETB 101	Inverness S	SC (1)
		65	65				
	34 79 *	 * ▼					
	:	▲ 65 75 ▼	:				
	35 35 *	. I ▲ *					
		75 					
	38 37 *	* ▼					
	39 24 *	1 75					
		A *					
Nigg LC (AHBC)	39 25	65					
	39 26 *	 					
		▲ 65 75 ▼					
		▲ 05 15 ¥					
	40 13 *	A *					
		75	65				

LOR	Seq.	Line of Ro	oute Descrip	tion		,	ELR	Route	Last Updated
SC203	013	Inverness					WCK	Scotland	02/12/06
	Loc	ation	Mile M	age Ch	Running lin	es & speed restrictions		Signalling &	Remarks
				43 * 45 *	15X TRAINS ONLY 75	OTHER THAN 15X TR	AINS	RETB 101 Inverse	ess SC (I)
Feam GF			40	46 (S) = _54	(\$) ■ 5.1			
FEARN 1	ΈP		40	60 T	sdg +	T sdg +		Permissive arrangeme RETB territory. PP(A) - detaching, for	
Hilton Mills	LC (UV	WC)	42	61 T]			movements only See Local Instructions conditions under which	
Balkeith S	outh LC	(UWC)	43	17 T]	T		detach $\langle \overline{2} \rangle = 15$ mph through loop	·
South end	loop po	ints	44	12 *	②* /	2 *		points, in both direction and over loop lines	ns,
TAIN TE	P		44	23	PP(A) ① sdg	T	sdg	CL 840f (255m) (40 SLU's) RETB 112	
Sdg GF North end	loop poi	ints	44	36 *	(2)}	(S) (2) (2) (E)		RETB 113	······································
				- 1	60	`60			

LOR Seq. Line of Rou				ELR	Route		
SC203 014 Inverness to				WCK	Scotlar		
Location	Mileage M Ch	Running	lines & speed restrictions		Signalling & Remarks		
		15X TRAINS ONLY	OTHER THAN 15X TRA	INS	RETB 113	inverness SC (I)	
		60	60				
	44 60 *	*					
Edderton No 1 LC (UWC)	48 46 <u>T</u>		T				
Manse LC (UWC)	49 20 <u>T</u>		T				
Ardvannie No 2 LC (UWC)	51 40 T		T				
	52 72 *	75 ‡	*				
	•	! 65 !	50 I				
	54 03 *	*	*				
Midfeam LC (UWC)	55 26 T	60	60				
Nesterfearn LC (UWC)	55 32 T		T				
	55 43 *						
		60	50				

LOR Seq. Line of Route I	Description		-	ELR	Route	Last Updated
SC203 015 Inverness to W				WCK	Scotland	02/12/06
Location	Mileage M Ch	Running lir	nes & speed restrictions		Signalling &	Remarks
	56 08 *	15X TRAINS ONLY	OTHER THAN 15X 50 1 *	TRAINS	RETB 113 Inverne:	ss SC (I)
Ardchronie LC (UWC)	56 40 T		T			
Kincardine Mains LC (UWC)	56 75 T		T			
McNicols LC (UWC)	57 32 T		T			
Sdg GF	(<u>\$</u>)	5 sdg	(\$) 5 sd	g		
ARDGAY TEP	57 70 T	+	T	-	CL 1430f (435m) (69 SLU's)	
	58 03 *	* 1	•		① = 15 mph through loop points, in both direction and over loop lines	s,
	58 55 *	 * 				
	58 56 *	 * 				
		70	60			

December 2006

LOR Seq. Line of Rou	te Description		ELR		Last Updated		
SC203 016 Inverness to			WCK	Scotland	02/12/06		
Location	Mileage M Ch	Running I	ines & speed restrictions	Signalling & Remarks			
Balnahinch No 4 LC (UWC)	59 78 T	15X TRAINS ONLY	OTHER THAN 15X TRAINS 60	RETB 113 Inv	remess SC (I)		
Culrain Smithey LC (UWC)	60 63 T		T				
CULRAIN	60 74 * 61 00 61 10 *	20	20				
INVERSHIN	61 34	45	40				
	63 05 *	* 35 * 45	* 30 * 40				

LOR Seq. Line of Rou				ELR	Route	Last Update	
SC203 017 Inverness t			Wo	CK	Scotland	02/12/06	
Location	Mileage M Ch	Running lin	nes & speed restrictions		Signalling & Remarks		
	64 19 *	15X TRAINS ONLY 45 * 1 50	OTHER THAN 15X TRAINS 40		RETB 113 Inverse ① ≈ 15 mph through loop points, in both directio	ess SC (I)	
Sdg GF	66 78 T sd	55	\$ = 5 T sdg		and over loop lines CL 990f (302m) (48 SLU's)		
Lairg LC (AOCL)	67 11 68 00 *	1 STOP ▼	<u>1</u> STOP ▼		A plunger is provided on the Up "Points Set" indicator post for shunting movement to the Up loop and when operated activates the LC light sequence		
Tomich No 1 LC (UWC)	68 54 T	- 55	40		light octaono		
Tomich No 2 LC (UWC)	68 64 T		T				
Acheilidh No 2 LC (ABCL)	70 00 *	* 40	40		RETB 126		
		\$55	▲ 55				

LOR S	Seq.	Lir	ne of	Route	Descri	ption								ELR	Ro	ute	Last Updated
SC203 (018	Inv	verne	ss to V										WCK	Scot	land	02/12/06
	Loca	atic	on		Mil	eage Ch			Rur	nning lines	& spee	d restrict	ions		Sig	nalling & F	Remarks
								15X T	70			THER THAI	1 15X TRA	ins	RETB 126	Invernes	s SC (I)
Rossal No 2 Rovie LC (Al		wc	;)			36	T	≜ 25	10 ▼		T		10 ▼				
									<u> </u>		57		:550		(1) = 15 mph thi points, in I and over I RETB 112	both directions	5
ROGART T	TEP				77	01	T		STOP		T		STOP	•	CL 1095f (330) (53 SLU's)	m)	
Rogart LC (d	open)				77	⁷ 08	A 1	10	1)		≜ 10	1			(33 320 8)		
West Kinnau	uld No:	2 L0	C (UW	C)	77	36	Ţ				Ť						
West Kinnau	uld No	3 L0	C (UW	C)	77	53	Ŧ				Т						
Kinnauld Ea	st No 1	1 LC	(UWC)	76	3 01	T				T						
Kinnauld Ea:	st No 2	2 LC	(UWC)	78	3 25	. []				T						
Morvich No	1 LC ((UW	C)		78	3 38	T	-			T						
Morvich No	3 LC (l	UW	C)		78	3 62	T				Т						
									70	-		12	0				

	te Description			ELR	Route	Last Updated
SC203 019 Inverness to				WCK	Scotland	02/12/06
Location	Mileage M Ch	Running lin	nes & speed restrictions		Signalling &	Remarks
		15X TRAINS ONLY	OTHER THAN 15X	TRAINS	RETB 112 Inverse	ss SC (I)
Morvich No 4 LC (UWC)	78 71 T	① 35 V ▲① 40	T		(1) = Applies on the approact Morvich No. 4 LC. Drive accelerate as soon as the	rs may
Morvich No 6 LC (UWC)	79 03 T		T		of the train is on the LC	е поп
Morvich No 7 LC (UWC)	79 22 T		T			
Morvich No 8 LC (UWC)	79 6 2		Т			
	80 20 *	 * 				
		1 60 				
	80 65 *	! *	*			
		55	45			
	81 47 *	 	*			
		`70				
	82 08 *	⊹ ▼				
Badden LC (UWC)	82 30 T		T			
		▲ 70 60 ▼				
	82 43 *	60	60			
		OU	60			

LOR Seq. Line of Rou	te Description			ELR	Route	Last Updated
SC203 020 Inverness to				WCK	Scotland	02/12/06
Location	Mileage M Ch	Running	lines & speed restrictions		Signalling	& Remarks
		15X TRAINS ONLY 60 55 ▼	OTHER THAN 15X 60 30 55 ▼	TRAINS	RETB 112 Inver	ness SC (I)
Kirkton LC (AOCL)	82 44 82 45 *	★ ▼	▲ 30 55			
	83 00 *	∆ 60 \ 70 \				
Culmaily No 2 LC (UWC)	83 17 T		T			
Culmaily No 3 LC (UWC)	83 34 T	70				
Drummule LC (UWC)	83 73 T		T			
	84 13 *	 * 	*			
GOLSPIE	84 30	45	40			
	84 51 *	 * 	! *			
Dunrobin LC (UWC)	86 19 T	· ** ** *** *	T			
		70	60			

LOR Seq. Line of Rout					LR	Roi		Last Updated
SC203 021 Inverness to				WCI	(Scot	and	02/12/06
Location	Mileage M Ch	Running	lines & speed	restrictions		Sig	nalling & F	Remarks
		15X TRAINS ONLY		OTHER THAN 15X TRAINS		RETB 112	Invernes	s SC (I)
DUNROBIN	86 22					l		J
Mellaig No 1 LC (UWC)	86 64 T		T					
	87 71 *	 * 		 * 				
	İ	60 1		45 				
	88 23 *	*		*				
Strathsteven LC (UWC)	88 27 T	70	T					
Doll LC (UWC)	89 02 T		T					
	89 13 *	* ▼		 * ▼ 				
MacBeaths LC (UWC)	89 24 <u>T</u>	▲ 70 30 ▼	T	≜ 60 30 ▼				
	89 25 *	 †▼		 *▼				
Inver Brora No 1 LC (UWC)	89 34 T	70	T	` 60 				
	:	70		60				

LOR Seq.	Line of Route	Description			ELR	Route	Last Updated
SC203 022	Inverness to		WCK			Scotland	02/12/06
Location		Mileage M Ch	Running li	nes & speed restrictions		Signalling &	Remarks
			15X TRAINS ONLY	OTHER THAN 15X TRAINS	3	RETB 112 Inverse	ess SC (I)
Inver Brora No 2 LC	(UWC)	89 68	Τ	T			
		89 75 *	<u> </u> *				
Brora LC (AOCL)		90 31	155 60 V 15 √	155 10 60 1 15 15 15	,	A plunger is provided under the stop board at the Rogar end of the platform for shunting movements to the single line which, when operated, inhibits the LC	
BRORA TEP		90 48	1	T 5 E		lights sequence CL 1220f (330m) (59 SLU's)	
McIvors LC (UWC)		90 71	T D	T D		15 mph through loop points, in both direction and over loop lines	ns,
East Brora Muir No	1 LC (UWC)	91 00	Ī	T			
East Brora Muir No	2 LC (UWC)	91 11		T			
Dalchalm LC (AOC	L)	91 30	▲ 50 ▼	25 50 ▼			
Greenhill LC (UWC)	92 05	<u> </u>	T			
Clynemilton East Lo	C (UWC)	92 40		Т			
		-	1 55 60 T	1 55 60 ₹			

	Line of Route De				ELR	Route	Last Updated
SC203 023	Inverness to Wic				WCK	Scotland	02/12/06
Location Mileage Running lines &		s & speed restrictions		Signalling & Remarks			
Kintradwell No 1 LC	(UWC)		15X TRAINS ONLY 155 60 1	OTHER THAN 15X TRAINS 1 55 60 1 * 1	3	RETB 112 Inverse	ess SC (I)
Kintradwell No 2 LC	(UWC)		T	55			
Old Castle LC (UW)	93 36 * 93 63 94 36 *	T. +	1 45 55 V			
Lothbeg LC (UWC)		94 53 * 95 03	 ^ *	45 T			
Culgower No 1 LC (uwc)	97 22	T	T			
Portgower No 1 LC	(UWC)	97 78 * 99 33	* 45	T 45			

28

LOR Seq. Line of Rout				ELR	Route	Last Updated
SC203 024 Inverness to				WCK	Scotland	02/12/06
Location	Mileage M Ch	Running I	ines & speed restrictions		Signalling &	Remarks
		15X TRAINS ONLY	OTHER THAN 15X TRAIN	NS	RETB 112 Inverse	ess SC (I)
Portgower Station LC (UWC)	99 73 T	1	T			
HELMSDALE TEP	101 40 T				CL 840f (255m) (40 SLU's)	
Sdg GF	(Š)	1 5 T	S 3 5 1		15 mph through loop points, in both direction	15.
Bual No 1 LC (UWC)	101 62 T	45	T		and over loop lines	
Bual No 2 LC (UWC)	101 75 T		· 			
Marrel LC (ABCL)	102 38	40 ▼	②▲ 20		(2) Differential permanent sprestriction. Lower speed to all trains except Class trains. Rule Book, Modu	applies 15X
	103 25 *	* 	*		Section 2.4 is modified accordingly	
	103 54 *	60 	▲ 40 45 ▼			
	105 68 *	50	* T			

	ute Description			ELR	Route		
SC203 025 Inverness				WCK	Scotlar	nd 02/12/06	
Location	Mileage M Ch	Running I	ines & speed restrictions		Signalling & Remarks		
		15X TRAINS ONLY	OTHER THAN 15X TRAIN	s	RETB 112	Inverness SC (I)	
		<u>50</u>	40				
	106 31 *	*▼ I `65	*				
	107 74 *	*▼	▲ 50 40 ▼				
Kilearnan LC (UWC)	108 38 <u>T</u>						
	110 47 *	55 I *▼	↓				
	110 47 *	▲ 55 45 ▼	▲ 50 45 ▼				
	110 68 *	 *					
		50 -					
Kildonan LC (Open)	111 03	STOP ▼	STOP ▼				
KILDONAN	111 05						
Learable LC (UWC)	111 74						
	113 20 *	 *	A *				
Borrobol LC (UWC)	114 74 T	·	T				
		55	▲ 40 45 ▼				

LOR Seq.	Line of Ro	ute Description			ELR	Route		
SC203 026	Inverness	to Wick			WCK	Scotlar	nd 02/12	2/06
Location		Mileage M Ch	Running line	s & speed restrictions		Signalling & Remarks		
KINBRACE	auon	115 62 * 116 23 * 118 08 *	15X TRAINS ONLY 55 1 50 1 55 1 50 1 55 50 1 55 50 1 55 50 1 55 50 1 55 1 55 1 55 1 50 1 55 1 55 1 50 1 55 1 50 1 1 50 1 1 50 1 1 50	OTHER THAN 15X TRAI 40 40 40 40 40 40 40 40 40 40 40 40 40	NS	RETB 112	Inverness SC (I)	
Kinbrace LC (AOC	:L)	118 24 * 118 25	55 20 V	50 10 20 ▼ ▲ 20 40				
		118 52 *	★ 50 65 V	50				

December 2006 31

Vick Mileage M Ch	Domino dia		WCK	Scotland	02/12/06
Mileage M Ch	Domein a lie				
	Location Mileage M Ch Running lines & speed restrictions			Signalling &	Remarks
121 00 T	15X TRAINS ONLY	OTHER THAN 15X TRAIN	IS	RETB 111 Inverne	ss SC (I)
123 71 *		* * 50			
125 24 * 45 CE Sdg 10 ▼ 125 67		(§) 5 € 10 ▼	Sdg	Plungers are provided at the Helmsdale end of the Down platform under the Down speed restriction board and at the exit from the CE siding for shunting movements and when operated activate the LC lights sequence	
125 69 T		(T)		CL 820f (250m) (40 SLU's) (1) = 15 mph through loop points, in both directio and over loop lines	ns,
127 35 *	50 * 60 	50			
	123 40 * 123 71 * 125 24 * 125 67 125 69	121 00 T 123 40 * 125 24 * 125 67 126 48 * 127 35 * 128 60 T	121 00	121 00	121 00

LOR Seq. Line of Rou	te Description			ELR	Route	Last Updated
SC203 028 Inverness to	o Wick			WCK	Scotland	02/12/06
Location	Mileage M Ch	Running	ines & speed restrictions		Signalling & Remarks	
		15X TRAINS ONLY	OTHER THAN 15X TRAIL	NS	RETB 111 Inverse	ess SC (I)
Altnabreac GF	133 73 S	<u>70</u>	§ 50 5			
ALTNABREAC	133 76				For engineers motor trolleys only	
	142 67 *		 			
	142 71 *		40 			
SCOTSCALDER	143 02		50			
Tongside No 1 LC (UWC)	143 30 T		T			
Tongside No 2 LC (UWC)	143 71 T	-	Т			
	144 72 *	 * 				
	145 37 *	50	 * - 40			

LOR Seq. Line of Route				ELR	Route	Last Update
SC203 029 Inverness to \				WCK	Scotland	02/12/06
Location	Mileage M Ch	Running lin	es & speed restrictions		Signalling &	Remarks
		15X TRAINS ONLY	OTHER THAN 15X TRAIN	S	RETB 111 Inverse	ess SC (I)
	145 40 *		*			
Halkirk LC (AOCL)	145 59		30 ▼ 10 50 50			
Halkirk TEP (Down direction only)	146 53 T	*	T		(1) = 15 mph through loop points, in both direction and over loop lines	ns,
South end loop points	147 09 *	*			(2) Permissive arrangement RETB territory. PP(C) Up / Down platform detaching only.	
Jp South GF	(Ś)	To Thurso SC207 seq	1 S To T SC20	Thurso 17 seq 1	See Local instructions for conditions under which train detach	ns may
BEORGEMAS JN TEP	147 20 T				CL 800f (240m) (39 SLU's) URS 655f (195m)	
Jp North GF	UF	RS PP(C) ②	URS PP(C) ②		Plungers are provided on the Up/Down line platform for operating the branch junction points under the instruction.	on s
Georgemas No 1 GF lorth end loop points	147 34 *	´ □ (1*3)	\$ 1 0 *3		of the signalier at Inverness (RETB) SC ③ = gf controlled loop point	
		60	60			

LOR Seq. Line of Route			ELR		Last Updated
SC203 030 Inverness to			WCK	Scotland	02/12/06
Location	Mileage M Ch	Running	lines & speed restrictions	Signalling 8	Remarks
		15X TRAINS ONLY	OTHER THAN 15X TRAINS	RETB 111 Invert	ess SC (I)
Bower TEP (Up direction only)	147 56 T	60			
Sibster Moss LC (UWC)	147 58 <u>T</u>				
	148 05 *	 *			
East Clayock LC (UWC)	148 54 T	 70	T		
Gelshfield Gates LC (UWC)	149 00 T		T		
Gelshfield LC (UWC)	149 28 T		T		
Loch View Farm LC (UWC)	149 48 <u>T</u>				
	150 20 *	 * 			
	150 40 *	60			
			50		
	151 74 *		* 20		
Watten LC (AOCL)	153 68	30 ▼	30 ▼		
		60	60		

35 December 2006

ne of Route Descr	iption			ELR	Route	Last Updated
verness to Wick				WCK	Scotland	02/12/06
on Mi M	leage Ch	Running lin	nes & speed restrictions		Signalling &	k Remarks
		15X TRAINS ONLY	OTHER THAN 15X TRAIN	IS	RETB 111 Inven	ness SC (I)
C) 15	4 61		T -			
15	6 26		T			
15	6 50 *	<u> </u>				
15	9 13 *	75 				
15	9 16 *	60 * 				
		75				
16	0 58 *	A *	A *			
		▲ 45 \ `75 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	▲ 45 60 ▼			
		5	5			
16	1 35	5 15	5 15			
	verness to Wick on Min Min Min Min Min Min Min Min Min Mi	Mileage M Ch 154 61 156 26 156 50 * 159 16 *	verness to Wick on	verness to Wick on	verness to Wick on	verness to Wick on

LOR Seq. Line of Route				ELR	Route	Last Updated	
SC205 001 Dingwall to K				(YL	Scotland	02/12/06	
Location	Mileage M Ch	Running line	es & speed restrictions		Signalling & Remarks		
Dingwall	0 19 SC	15X TRAINS ONLY	OTHER THAN 15X TRAINS		RETB 102 Inverse	ess SC (I)	
Dingwall Canal North LC (UWC)	0 20 *	45	40 1 20		① = 15 mph through loop points, in both directi and over loop fines	ons,	
	0 48 *	* 40	* 10				
Dingwall No 1 LC (AOCL)	0 57	20 ♥	10 V				
Dingwall Middle LC (AOCL)	0 67	20 ▼	10 ▼ 20 ▼				
Dingwall No 2 LC (AOCL)	1 05	20 ▼	10 ▼ 10 20 ▼				
		40	40				

December 2006 37

LOR Seq. Line of Rout				ELR	Route	Last Updated
SC205 002 Dingwall to	Kyle of Lochalsh			KYL	Scotland	02/12/06
Location	Mileage M Ch	Running li	nes & speed restrictions		Signalling	& Remarks
		15X TRAINS ONLY	OTHER THAN 15X TRA	INS	RETB 102 Inve	erness SC (I)
	1 05 *	 * 			RETB 105	
	2 17 *		* 35			_ :
Foderty TEP	2 31 T	†	<u> </u>			
	2 41 *	\ \ \ \	* 20			
	2 53 *		 * 35			
	3 09 *		*			
Keppoch LC (UWC)	3 64 T	*				
		40	40			

	ute Description		EL		
C205 003 Dingwall to	Kyle of Lochalsh		KYL	Scotla	
Location	Mileage M Ch	Running line	es & speed restrictions	Sign	alling & Remarks
		15X TRAINS ONLY	OTHER THAN 15X TRAINS	RETB 105	Inverness SC (I)
		40 ▼	40 ▼		
htemeed LC (AOCL)	4 55	▲ 20	▲ 20		
	i	40			
	5 30 *	! *			
		35 	30		
	6 26 *	* I	* 		
	6 71 *		40		
		40	20		
	6 76 *		<u> </u>		
	7 30 *				
	:	40	30		

December 2006 39

LOR Seq. Line of I	Route Description		ELR	Route	Last Updated
SC205 004 Dingwa	Il to Kyle Lochalsh		KYL	Scotland	02/12/06
Location	Mileage M Ch	Running lir	nes & speed restrictions	Signalling &	Remarks
		15X TRAINS ONLY	OTHER THAN 15X TRAINS	RETB 105 Inverse	ess SC (I)
Rogie LC (UWC)	8 08	T	T		
	10 32 *:]	*		
Killin Farm No 2 LC (UWC)	11 23	40	40		
Killin Farm No 3 LC (UWC)	11 40	(T)	(1) (1)	(1) = 15 mph through loop	
Sdg GF		(§)	(s)	points, in both directions, and over loop lines	
GARVE TEP	11 65	Loading Bank	Loading Bank	CL 800f (240m) (39 SLU's)	
Garve LC (AOCL)	11 72	STOP ▼	STOP ▼	A plunger is provided at the Up direction board worder "Shunting Press Plunger of White Light and Whistle El Proceeding" which, when operated, activates the LC	d O btain defore
Gorstan LC (UWC)	11 74 *	45	35	sequence	, ng 10

		ELR	Route	Last Updated
		KYL	Scotland	02/12/06
Running lines & s	peed restrictions		Signalling	& Remarks
RAINS ONLY	OTHER THAN 15X TRAINS	S	RETB 105 Inve	emess SC (I)
T	*			
45	40			
- I				
4				
	 * 			
	1 30 * 20			
	 * 30	,		
45	 - 40			
	45	<u> </u>	<u> </u>	*

LOR Seq. Line of Ro				ELR	Route	Last Updated
SC205 006 Dingwall to	Kyle Lochalsh			KYL	Scotland	02/12/06
Location	Mileage M Ch	Running li	nes & speed restric	ctions	Signalling	& Remarks
	21 22 *	15X TRAINS ONLY 45		NN 15X TRAINS	RETB 105 Inve	emess SC (I)
	21 30 *	40 • * 20		* 20		
ACHANALT	21 34					
	21 38 *	 		 * 		
	21 43 *	<u></u> 		40 		
Strath LC (UWC)	22 31 T	45	T			
Rose Bank LC (UWC)	23 18 <u>T</u>		T	1		
	25 76 * 26 44 *	*		* 1 35 ! * 40		

LOR Seq. Line of Rou				ELR	Route	Last Updated
	Kyle of Lochalsh			KYL	Scotland	02/12/06
Location	Mileage M Ch	Running lir	es & speed restrictions		Signalling &	Remarks
Quarry Burn LC (UWC)	27 20	15X TRAINS ONLY	OTHER THAN 15X TRA	NINS	RETB 105 Inverse	ess SC (I)
East end loop points	27 50 *	_ 1	(h)		1) = 15mph through loop points, in both directi and over loop lines	ons,
Sdg GF	\$	5 4	\$ 3 5			
ACHNASHEEN TEP	27 72 <u>T</u>				CL 1010f (305m) (49 SLU's)	
		Linii Mari			RETB 104	
Nest end loop points	27 77 *	①* 45	(t)		L	
Craig LC (UWC)	38 03 <u>T</u>		·		RETB 108	: :
	40 24 *	 * 				
ACHNASHELLACH	40 34					
	40 67 *	40 *				
	:	45	40			

LOR Seq. Line of Rou			ELR KYL	Route Scotland	02/12/06
SC205 008 Dingwall to	Mileage				
Location	M Ch	Running I	ines & speed restrictions	Signalling &	Remarks
	41 71 *	15X TRAINS ONLY 45 45 40	OTHER THAN 15X TRAINS	RETB 108 Inverne:	ss SC (I)
Belnacra LC (AOCL)	42 12	4 0 20 ▼	20 ▼		
Balnacra No 2 LC (UWC)	42 44 * 42 58 T	*	<u></u>		
Coulags No 1 LC (UWC)	43 32 T	-20-00-0	T		
Blackwood No 1 LC (UWC)	44 35 T	·	40	1 = 15 mph through loop points, in both direction and over loop lines	os,
Blackwood No 2 LC (UWC)	44 67 T	$\blacktriangle_{\overline{45}_{1}}^{\underline{35}} - 25 $	<u>T</u> <u>35</u> <u>25</u> ▼	CL 780f (235m) (38 SLU's)	
6dg GF	(<u>\$</u>)	5	(§ 3) (Fig. 1) (Fig. 1)	Drivers must sound the locomotive horn CONTINUC	
STRATHCARRON TEP	45 74 <u>T</u>	منا وا	Sdg LLL	from the Stop Board until ov the crossing. Plungers are provided for shunting	
strathcarron LC (AOCL)	45 77	\$TOP▼	▲ 15	movements to the Up loop of the speed restriction board the approach to the facing points for the Up loop and for	at
V est end loop points	46 01 *	© ;	0	a Down direction movement the Up line on the Stop Boa at the approach to the cross which, when operated, activ	t on Ird Sing
		40	40	the LC lights sequence	

LOR Seq. Line of Ro			ELR	Route	Last Updated
SC205 009 Dingwall to	Kyle Lochalsh		KYL	Scotland	02/12/06
Location	Mileage M Ch	Running li	nes & speed restrictions	Signalling	g & Remarks
Auchintee LC (UWC)	46 15 T	15X TRAINS ONLY	OTHER THAN 15X TRAINS 40 T	RETB 108 Inv	emess SC (I)
ATTADALE	48 22 48 62 *	35	35		
STROMEFERRY	53 15 53 26 *	25	25		
DUNCRAIG	57 09	30	30		

45 December 2006

OR Seq. Line of Route					ELR	Rou		Last Update
C205 010 Dingwall to K		1			KYL	Scotl	-	02/12/06
Location	Mileage M Ch	<u> </u>	Running lines & s	peed restrictions		Sig	nalling & R	emarks
		15X TRAINS	ONLY	OTHER THAN 15X	TRAINS	RETB 108	Invernes	sc (I)
		30		30				
LOCKTON	58 22		:					
uirinish Station LC (UWC)	59 56				7			
UIRINISH	59 58	i.	0/(Zazimi).					
:F		(S)) (\$)		1			
" F		\$ 15	9	15 ■				
		5 ▲15▼ ▲15▼		5 ▲15▼ ▲15▼				
		West Sdgs		West Sdgs				
F		<u>\$</u> 5	East Sdgs		East Sdgs			
YLE OF LOCHALSH TEP	63 64		T					

LOR Seq. Line	of Route Description			ELR	Route	Last Updated	
SC207 001 Georg	gemas Jn to Thurso		Scotland	02/12/06			
Location	Mileage M Ch	Running lin	nes & speed restrictions		Signalling & Remarks		
		15X TRAINS ONLY SC203 seq 29	OTHER THAN 15.	X TRAINS	RETB 111 Inverne	ss SC (I)	
Georgemas Jn	0 00	15:11	15.1		Plungers are provided on the Up/Down platform for operat the branch junction points ur	ing	
Hoy LC (AOCL)	0 72	40	20 40		the instructions of the signall at Inverness (RETB) SC		
Gunn LC (UWC)	1 05	T	T		① = Through jn points		
Blackhillock LC (UWC)	1 17 *	1	 T		See Local Instructions for conditions under which a sec train may be admitted to the Up/Down platform line when		
Sordale No 1 LC (UWC)	1 59	<u>T</u>	T		occupied.		
	4 04 *:	* 1 40	40		See Local Instructions for definition of a "Long Section"		
	4 25 *	! ! 60			as applying in both directions between Georgemas Jn and Thurso		
Sdg GF		(\$) 5 Dock	(S) 5 5 5	ock			
Stn GF THURSO TEP	6 50	S Line	\$ 15 ▼ Lir				

This page is intentially blank

SPECIAL WORKING ARRANGEMENT Table of Contents

SC203- INVERNESS TO WICK Page 50

SC203 (INVERNESS TO WICK)

Trains or vehicles may be propelled in accordance with the Rule Book, Module TW1, Section 13 where shown below. These authorities are subject to any special conditions as to speed, length (feet with metric equivalent) or other feature as shown in the 'Restrictions' column.

From	То	Type of Train	Line(s)	Remarks
Millburn Yard	Rose Street	Freight	Up main, Rose Street Curve	Trains not exceeding 210ft (64m) excluding locomotive may be propelled.
Rose Street	Millburn Yard	Freight	Rose Street Curve, Up main	Trains not exceeding 210ft (64m) excluding locomotive may be propelled.

ROUTE CLEARANCE Table of Contents

	Table of Contents			
Page				
AINS 52	TABLE D1 - ROUTE CLEARANCE OF DIESEL MULTIPLE UNIT TRAINS			

Table D1 - Route clearance of diesel multiple unit trains

To be read in conjunction with General Notes.

Line of route	Line of Route / Sector Description	Her	14X	150	153	155	156	158	170	Notes
SC203	INVERNESS TO WICK	Y	N	Y	Y	Y	Y	R1	N	R1 Approach speed to platform 6, (from the top of the ramp), must not exceed 10 mph.
SC205	DINGWALL TO KYLE OF LOCHALSH	Y	N	Y	Y	Y	Υ	R1	N	R1 Lochluichart platform - 25mph Stromeferry platform - 15mph Duncraig platform - 25mph
SC207	GEORGEMAS JN. TO THURSO	Y	N	Y	Υ	Υ	Y	R1	N	R1 Thurso platform - walking pace only

Dece₁ J06 52

LOCAL INSTRUCTIONS Table of Contents

	<u>Page</u>
SC203- INVERNESS TO WICK	
INVERNESS TO CLUNES TEP	54
INVERNESS	55
BEAULY	56
DINGWALL TEP	57
DINGWALL TEP TO ALNESS	58
TAIN TEP	58
LAIRG TEP	59
HALKIRK TEP (DOWN DIRECTION ONLY)	59
GEORGEMAS JN TEP TO WICK TEP	59
GEORGEMAS JN TEP	60
BOWER TEP (UP DIRECTION ONLY)	62
WICK TEP	62
ENTIRE LINE OF ROUTE	62
ENTINE EINE OF NOOTE	ŰŽ.
SC205- DINGWALL TO KYLE OF LOCHALSH	
STRATHCARRON TEP TO KYLE OF LOCHALSH TEP	63
KYLE OF LOCHALSH TEP	63
ENTIRE LINE OF ROUTE	63
ENTINE BINE OF NOOTE	03
SC207- GEORGEMAS JN TO THURSO	
GEORGEMAS JN TO THURSO TEP	64
THURSO TEP	64
ENTIRE LINE OF ROUTE	65
LIVING LIVE OF MOOTE	03

SC203 - INVERNESS TO WICK

INVERNESS To Clunes TEP

Viaduct over River Ness - If an Up or Down locomotive hauled passenger train is brought to a stand on the Ness Viaduct after sunset or during falling snow through exceptional or unforeseen circumstances, the guard (or guards, if there is more than one) must take steps at once to prevent any passengers attempting to alight from the train.

Authority for trains from Inverness to proceed on the North line - Provided the driver has received the appropriate token, the authority to proceed towards Clunes will be the clearing of the North line Down direction signal 1429 or 1427, as appropriate, followed by the clearing of Clachnaharry Down signal, or permission to pass one or both of these signals at danger.

Receiving/returning RETB tokens - A driver may enter the RETB system and obtain a token to proceed from Inverness towards Clunes at any place up to, or at, Down direction signal I429 or I427, as appropriate, but this procedure must be carried out when the train is at a stand. A driver proceeding to Inverness from the North line may surrender his token at any time after coming within the protection of Up direction North line signal I430, but this procedure must be carried out when the train is at a stand.

Failure of token issuing/receiving apparatus - The supply of special authority cards for the working of trains from Inverness to Clunes during a failure of token equipment is kept in a lockfast box at the notice board denoting the commencement of Radio Token Working. However, a traction unit will not be allowed to proceed to the North line (for the purpose of completing an authority card) unless radio contact is available between the driver and the signaller at Inverness (RETB) SC.

Engineer's Possession - When the driver of an engineer's train or machine requiring to leave a possession between Clunes and Inverness has received verbal permission to pass the Station Limits board towards Inverness, he must inform the signaller at Inverness (RETB) SC when the whole of his train is within the protection of Up direction signal I430.

Examination of line between Inverness and Clachnaharry - If a driver is instructed to report the state of the line between Inverness and Clachnaharry, the signaller at Inverness (RETB) SC will give him instructions regarding the point at which the driver must report, and whether he must use a telephone or radio for this purpose.

Shunting on North line - Permission to pass I427 or I429 for shunting purposes on the North single line gives the driver authority to proceed only as far as the notice board denoting the commencement of Radio Token Working.

Single line block section - The Up direction single line block section between Clunes and Inverness is defined as the line between the Up stop board at Clunes and the notice board denoting the end of Radio Token Working at Inverness.

The Down direction single line block section between Inverness and Clunes is defined as the line between the notice board denoting the commencement of Radio Token Working at Inverness and the Down stop board at Clunes.

SC203 - INVERNESS TO WICK

INVERNESS

Washing plant - The washing plant is fully automatic. The "WASH" indication will normally be displayed. Drivers of trains which require to proceed through the washing plant without washing must stop and press the plunger provided on the immediate approach to the plant. This will alter the indicator to display "NO WASH".

When trains are worked through the washing plant and the wash equipment is operating, speed must not exceed 3 m.p.h until the last vehicle is clear of the plant at the Millburn Jn. end.

If an incorrect indication is displayed, or where no indication is exhibited, the driver may proceed at 3 m.p.h. through the plant and must report the failure to the signaller at signal I708 or, if the last vehicle is not clear of the plant, at the first suitable opportunity.

If a failure occurs, where appropriate, the plunger must be operated a second time. If the correct indication is still not exhibited the driver must proceed as above.

Washer line - Movements must not be propelled. The line must be used in the Up direction only and all movements must proceed through to the Millburn Jn. end.

The splitting of trains on this line is prohibited.

INVERNESS T&RSD

Where reference is made in the following instructions to "designated person", this means the person responsible for protection in the depot who is identified by an orange armband bearing the letters "DP" in black.

Servicing Depot - Movements to and from Depot sidings - The following instructions apply to:-

Traction Maintenance Depot Sidings, Nos. 1 and 2

Cleaning Shed siding

Carriage Maintenance Depot sidings, Nos. 1 and 2

- When required to make a movement into the Shed or sidings concerned, the driver must stop at the signal situated on the approach to the Shed Doors.
- 2. The shunter must depress the plunger mounted on the signal. The plunger must not be operated until the train is at a stand at the signal. If the designated person has removed all the protection inside the Shed, opened the Shed doors and lowered the wheel stops, the signal will show a proceed aspect. The driver may then proceed with the movement as far as the line is clear, keeping a good lookout at all times for any persons or obstructions.
- 3. If after the plunger has been depressed the Shed doors remain closed and the signal continues to display a stop aspect, the shunter must request the designated person to remove the protection. When this has been done, the shunter, must again depress the plunger on the signal to change it to a proceed aspect. The movement may then proceed as far as the line is clear.
- 4. A movement out of a Shed must not be started unless the signal concerned at the Shed door is showing a proceed aspect or the conditions detailed in Clause 7 have been met. A movement must only proceed as far as the line is clear. These instructions also apply when the whole of the train is not within the Shed in which case the shunter is responsible for advising the driver when the Shed exit signal concerned is showing a proceed aspect.
- No vehicle or part of a vehicle must be allowed to pass a signal showing a stop aspect except during failure and then only under direct supervision of the designated person.
- The passing of a red signal will be treated in the same way as a signal passed at danger except in the circumstances detailed in Clause 7.
- 7. If the signals into or out of a Shed fail when a movement is required, then the vehicle must stop at the signal and must only proceed as far as the line is clear after the designated person has personally advised the driver and shunter that protection has been removed and the stop aspect signal may be passed.

Wagon Shop sidings Nos. 1 - 4 and Stores siding

- 1. When required to make a movement into the Wagon Shop or Stores siding, the driver must stop at the stop board.
- Movements past a stop board and movements out of the Wagon Shop on sidings 1, 2, 3 and 4 or from the Stores siding must not be made until the designated person has personally given the Shunter or Driver an assurance that it is safe for the movement to commence.

Fuelling Road

The coupling / uncoupling of Class 15X units on this line is prohibited.

Additional instructions for movements to the Traction Maintenance depot and Fuelling Road

Prior to a movement being made to the Traction Maintenance Depot or the Fuelling Road, the person in charge of the movement must obtain the permission of the person in charge at the depot for the movement to be made.

When required to make a movement into the depot or the fuelling road, the driver must stop at the stop board located at the entrance to the depot or the Fuelling Road.

Movements beyond the stop board must not be made unless the designated person has personally given the person in charge of the movement permission for the movement to proceed. The designated person must ensure that, in the case of the Fuelling Road, the appropriate rail stop is in the lowered position.

Dated: 02/12/06

SC203 - INVERNESS TO WICK BEAULY

The single platform is 16 yards long and special instructions are issued by ScotRail for ScotRail trains requiring to stop at this station. Trains, other than those covered by the ScotRail instructions, are prohibited from stopping, except in an emergency, or with prior authority received from the Network Rail Regional Operations Safety Manager.

SC203 - INVERNESS TO WICK

DINGWALL TEP

Shunting at North end - When requesting a 'Shunt' token, the driver and signaller must come to a clear understanding as to whether shunting is to be carried out on the main line to Invergordon or the branch line to Garve.

Junction and North end loop points - The hydraulic spring-controlled North end crossing loop points are train operated in accordance with the standard arrangements for RETB crossing loops. The junction points are power operated clamp points, and are plunger operated for Down direction movements and track circuit operated for Up direction movements.

Two pairs of plungers are provided at the North end of the station, one pair in association with the Down line 'Points Set' indicator, and one pair in association with the Up loop 'Points Set' indicator. These plungers must be operated only under the instructions of the signaller at Inverness (RETB) SC. Pressing the left-hand plunger of a pair of plungers sets the junction points for the Kyle branch. Pressing the right-hand plunger of a pair of plungers sets the points for the main line towards Evanton.

The illumination of the appropriate 'Points Set' indicator together with the correct route indication - 'B' for the branch or 'M' for the main line - after the operation of a plunger, prove that the junction points are correctly set and locked for the route chosen. Only the pair of plungers at the 'Points Set' indicator at which the train is standing can be used.

Additionally, a duplicate set of two plungers for the Down line 'Points Set' indicator, is provided under the station overbridge on the Down platform, operation as above. These duplicate plungers can only be used when a train is standing on the Down line either at these plungers, or at the Down line 'Points Set' indicator.

a) Down direction trains - When the driver of a Down direction train has been issued with a token and is ready to proceed, the signaller at Inverness (RETB) SC will instruct him to press the appropriate plunger. After this has been done the driver must inform the signaller whether the 'Points Set' indication, and the correct route indication, have illuminated. On confirmation of this, the signaller will give the driver verbal permission to proceed past the combined stop board and 'Points Set' indicator, provided that these indications remain illuminated.

If either of these indications fail to illuminate when a plunger is operated, or if the indications illuminate but extinguish before the train can proceed past the 'Points Set' indicator, then the driver must communicate with the signaller and act in accordance with his instructions.

- b) Up direction trains If the driver of an Up train on the main or branch line finds that the 'Points Set' indicator on the approach to Dingwall is not illuminated he must immediately inform the signaller at Inverness (RETB) SC who will instruct him to unlock the lockfast box beside the indicator post and report the indications displayed inside. The driver must then act in accordance with the instructions of the signaller, and must not proceed past the indicator without the verbal permission of the signaller. Clause 6.2 of instruction 6 of the Single Lines Worked by Radio Electronic Token Block Instructions to Traincrews, Persons carrying out Engineering Work and Others Concerned, is modified accordingly. When such verbal permission is given, the driver must not proceed until he has relocked the box and confirmed to the signaller that this has been done.
- c) Failure of North end loop points When, because of failure of the 'Points Set' indicator to illuminate, the driver of an Up direction train is instructed by the signaller at Inverness (RETB) SC to manually operate the North end loop points, he must operate the points to the required position and clamp and scotch them in that position. An assurance must be given to the signaller at Inverness (RETB) SC when this has been done.

The driver must not pass the 'Points Set' indicator unless the signaller at Inverness (RETB) SC has given permission to do so and the lockfast box at the 'Points Set' indicator has been relocked. When the train has passed clear of the points, the clamp and scotch must be removed, returned to the receptacle provided and an assurance to this effect given to the signaller at Inverness (RETB) SC when this has been done.

- d) Override switch for junction points The override switch for the junction points is located in the lockfast box adjacent to these points. This override switch normally lies in the central position. Switching it to the left sets the points for the main line. Switching it to the right sets the points for the Kyle branch. When operated to a position, the switch will remain in this position until it is again operated. This switch must only be operated under the instructions of the signaller at Inverness (RETB) SC. If instructed by the signaller to operate this switch, the driver, or other person concerned, must carry out the following procedure:-
 - (i) If the points are already in the correct position for the route required, the driver, or person concerned, must operate the switch for the other route, check that the points have moved to the other route, and then operate the switch to the route required and check that the points have moved to the route required.
 - (ii) If the points are not already in the correct position for the route required, the driver, or person concerned, must operate the switch for the route required and check that the points have moved to this position. He must then operate the switch for the other route, check that the points have moved to this position, and then operate the switch for the required route again, and check that the points are in the correct position for the route required.

If the override switch fails to move the points to the required position, the driver, or person concerned, must report this to the signaller, who will send for the person appointed to manually operate the junction points. The driver must not pass the 'Points Set' indicator until he receives the verbal permission of the signaller.

If the points have been operated to the required position the driver must confirm this to the signaller. The driver of a Down direction train must operate the appropriate plunger again, when so instructed by the signaller, and must then follow the appropriate instructions under the heading 'Down direction trains'.

The driver of an Up direction train must report to the signaller whether the 'Points Set' indicator is now illuminated, and must then act on the instructions of the signaller. He must not pass the 'Points Set' indicator without the verbal permission of the signaller. When such permission is given, before proceeding, the driver must relock the lockfast box beside the indicator post and confirm to the signaller that this has been done.

When the driver of an Up or Down direction train has proceeded over the junction points after the operation of the override switch, and the train is clear of both the loop points and the junction points, he must return the override switch to the central position, relock the box and confirm to the signaller when this has been done.

e) Engineers' machines - An engineer's machine which cannot be relied upon to actuate track circuits must not
proceed over the junction points to / from Foddarty until the override switch has been operated under the instructions
of the signaller at Inverness (RETB) SC.

Drivers of Down direction machines will be instructed to operate the override switch before operating the appropriate plunger.

Drivers of Up direction machines must stop at the 'Points Set' indicator on the approach to Dingwall, even if it is illuminated and act under the instructions of the signaller.

The override switch must be operated in accordance with the previous instructions under the heading **Override** switch for junction points.

Engineering possessions - If an engineering possession is required between the two single-sided Station Limits boards between Dingwall and Fodderty, the engineer must be in possession of both the Dingwall / Fodderty 'Engineering' token and also the Dingwall 'Shunt' token. Before the signaller issues the 'Shunt' token, the engineer must set the junction points for the branch under the instructions of the signaller, and in accordance with the instructions under the heading Override switch for junction points. When the 'Shunt' token is returned, the engineer must confirm to the signaller that the override switch has been returned to the central position, and the box relocked.

CE siding - If a train or engineer's machine requires to depart from the CE siding and proceed over the junction points towards Evanton or Fodderty, the driver must not proceed past the Down loop stop board until he has operated the appropriate plunger under the instructions of the signaller at Inverness (RETB) SC.

RETB Working by Pilotman - When RETB Working by Pilotman is in operation, a Network Rail Production Department Supervisor must be appointed at Dingwall to control all movements within Station Limits. The Network Rail area operations supervisor must conduct all trains arriving from Garve or Invergordon from the appropriate Station Limits board and must be present when any shunting at Dingwall takes place and when trains for Garve or Invergordon depart. The Network Rail area operations supervisor may also act as Pilotman between Muir of Ord and Dingwall.

Splitting of trains – Before uncoupling is carried out, the radio number of the rear train must be entered in the system. A train must not be split unless each portion has at least one radio in working order.

Dated: 02/12/06

SC203 - INVERNESS TO WICK

DINGWALL TEP To ALNESS

Foulis level crossing - A special speed restriction of 5mph in the Up and Down direction applies between 22 miles 1660 yards and 22 miles 1680 yards, on the approach to the crossing, applicable only to Engineer's Self-Propelled On-Track machines. This restriction is associated with problems with the operation of the crossing controls for these vehicles and is not signed on the ground.

Dated: 02/12/06

SC203 - INVERNESS TO WICK

TAIN TEP

Splitting of trains – Before uncoupling is carried out, the radio number of the rear train must be entered in the system. A train must not be split unless each portion has at least one radio in working order.

SC203 - INVERNESS TO WICK

LAIRG TEP

Drivers of Up direction freight trains exceeding 50SLU must immediately advise the signaller on arrival at Lairg Up loop stop board if there is a likelihood that a token exchange will not be carried out immediately for whatever reason eg. Rear cab token exchange.

In this event, the signaller will instruct the driver, after applying the appropriate RETB safeguards, to draw forward beyond the stop board ONLY AS FAR AS IS NECESSARY TO ENABLE THE REAR OF THE TRAIN TO CLEAR THE LEVEL CROSSING AT THE NORTH END OF THE LOOP.

The driver must advise the signaller when the train is again at a stand and give the signaller an assurance that no further movement will be made until a token exchange has been carried out. Thereafter, the driver must co-operate with the signaller in the appropriate token exchange.

Dated: 02/12/06

SC203 - INVERNESS TO WICK

Halkirk TEP (Down direction only)

Drivers are exempt from carrying out the 'loop clear' procedure after passing Halkirk.

Dated: 02/12/06

SC203 - INVERNESS TO WICK

GEORGEMAS JN TEP To WICK TEP

Single line block section - The Down direction single line block section is defined as the line between the stop board at Georgemas Jn and the designated line buffer stop at Wick.

SC203 - INVERNESS TO WICK

GEORGEMAS JN TEP

CE siding - This siding must only be used by engineer's machines.

When a movement requires to be made to or from this siding, the person in charge of the movement must advise the signaller what is required.

A scotch block is provided at the exit from the siding and the person in charge must ensure that it is removed before a movement from the siding commences, and is replaced after a machine has been stabled.

CE siding loop - Vehicles must not be stabled on this loop.

Thurso branch junction points - the points are power operated clamp locks, plunger operated for movements in the facing direction from Georgemas and actuated by track circuit for movements from the Forsinard and Thurso directions.

Plungers, for the operation of the points under the instructions of the signaller at Inverness (RETB) SC, are provided at the south end of Georgemas Up / Down platform opposite a stop board which must not be passed unless the correct indication is received. The plungers are labelled "M" and "B" for the Up (main) single line and branch line respectively. Pressing the appropriate plunger will illuminate a route indicator, indication "M" or "B" as appropriate, at the junction "Points Set" indicator. After the operation of a plunger, the appropriate route indication, together with the junction "Points Set" indicator illuminated, proves that the junction points are correctly set and locked for the route chosen.

a) Movement from Georgemas - When the driver of an Up direction train has come to a stand at the stop board adjacent to the platform, the signaller must be advised and his permission obtained to operate the appropriate plunger. On receipt of this authority, the driver must press the appropriate plunger and inform the signaller whether the "Points Set" indication, and the correct route indication, have illuminated. On confirmation of this, the signaller will give the driver verbal permission to proceed past the stop board and the "Points Set" indicator at the junction points, provided that these indications remain illuminated.

Where a token exchange is carried out in the platform, the token exchange procedure must be carried out before operation of the plunger in accordance with the above.

If either of these indications fall to illuminate when a plunger is operated, or if the indications illuminate but extinguish before the train can proceed past the "Points Set" indicator, the driver must communicate with the signaller and act in accordance with his instructions.

- b) Movement from Down single line or Up branch to Georgemas Up / Down platform If the driver of a train finds that the "Points Set" indicator on the immediate approach to the branch junction points (Down single line) or at the Up branch stop board is not illuminated, the signaller must be immediately informed and the driver must, thereafter, act in accordance with the signaller's instructions. Instruction 8 of the Single Lines Worked by Radio Electronic Token Block Instructions to Traincrews, Persons carrying out Engineering Work and Others Concerned is modified accordingly.
- c) Override switch for junction points The override switch for the junction points is located in the lockfast box on Georgemas Up / Down platform, adjacent to the plungers for the junction points and must only be operated under the instructions of the signaller.

The override switch normally lies in the central position. Switching it to the left sets the points for the Up / Down single line. Switching it to the right sets the points for the branch. When operated, the switch will remain in the position selected until it is again operated. When instructed by the signaller to operate this switch, the driver, or other person concerned, must carry out the following procedure:

- (i) If the points are already in the correct position for the route required, the driver, or person concerned, must operate the switch for the other route, check that the points have moved to the other route, and then operate the switch to the route required and check that the points have moved to the route required.
- (ii) If the points are not already in the correct position for the route required, the driver, or person concerned, must operate the switch for the route required and check that the points have moved to this position. He must then operate the switch for the other route, check that the points have moved to this position, and then operate the switch for the required route again, and check that the points are in the correct position for the route required.

If the override switch fails to move the points to the required position, the driver, or person concerned, must report this to the signaller, who will send for the person appointed to manually operate the junction points. The driver must not pass the 'Points Set' indicator/stop board until he receives the verbal permission of the signaller.

If the points have been operated to the required position the driver must confirm this to the signaller. The driver of a train from Georgemas Up / Down platform must operate the appropriate plunger again, when so instructed by the signaller, and must then follow the instructions under the heading "Movement from Georgemas Up / Down platform".

The driver of a train from the Down single line or the Up branch must report to the signaller whether the 'Points Set' indicator is now illuminated, and must then act on the instructions of the signaller. He must not pass the 'Points Set' indicator without the verbal permission of the signaller.

When a train has proceeded over the junction points after the operation of the override switch, and the train is clear of the junction points, the driver, or person concerned, must return the override switch to the central position, relock the box and confirm to the signaller when this has been done.

d) Engineer's machines - movements to / from branch - An engineer's machine which cannot be relied upon to actuate track circuits must not proceed over the junction points to / from the Thurso branch until the override switch has been operated under the instructions of the signaller.

Drivers of Down direction machines (to the branch) will be instructed to operate the override switch before operating the appropriate plunger.

Drivers of Up direction machines issued with a "Long section" token Thurso / Georgemas must stop at the "Points Set" indicator at the Thurso branch Up stop board, even if it is illuminated, and act under the instructions of the signaller. Where a "section" token Thurso / Georgemas has been issued, the token exchange procedure must be carried out at the Up branch stop board before the override switch is operated.

The override switch must be operated in accordance with the previous instructions under the heading "Override switch for junction points".

Shunting - When requesting a "shunt" token, the driver must advise the signaller whether it will be necessary to operate the Thurso branch junction points. If so, the driver and signaller must come to a clear understanding as to whether shunting is to be carried out on the Up / Down single line towards Forsinard or on the Thurso branch.

Joining and splitting of trains and connecting services - The following arrangements apply:-

Joining or connecting services on Up / Down platform Line :-

In all cases, where a joining / connecting movement is required from the Thurso branch, such movement must be the first to be made towards the Up / Down platform line.

(i) **Train from Thurso** - A train from Thurso booked to join, or connect with, a Southbound service, will be issued with a "Shunt" token at Georgemas Up branch stop board, and the driver instructed, when being given permission to proceed, to bring his train to a stand on the Up platform line, opposite the stopping marker, and return the "Shunt" token.

A train from Thurso booked to connect with a Northbound service, and to then proceed to Wick, will be issued with a "Shunt" token at Georgemas Up branch stop board, provided that permission to proceed has not been given to the connecting train at Halkirk, and Georgemas Up / Down platform line is clear throughout. The driver, when being given permission to proceed, will be instructed to pass the stopping marker, and to proceed towards the Down stop board on Georgemas Down platform line, so as to position his train wholly on the Wick side of the stopping marker, and to then return the "Shunt" token.

(ii) Train from Wick - A train from Wick booked to join, or connect with, a Southbound service, or to connect with a Northbound service, will be issued with a "Bower / Georgemas Occupied" token at Bower, and the driver instructed, when being given permission to proceed, to bring his train to a stand on the Up platform line, opposite the stopping marker, and to return the token. The driver will be reminded that the Up / Down platform line is occupied.

In the event of a failure of all cab equipment in the train from Bower, a special authority card may be used provided Clause (a) on the special authority card is endorsed "Loop Occ".

(iii) **Train from Forsinard** - A train from Forsinard booked to connect with a service to Wick will be issued with a "Halkirk / Georgemas Occupied" token at Halkirk, and the driver instructed, when being given permission to proceed, to bring his train to a stand on the Down platform line, opposite the stopping marker, and to return the token. The driver will be reminded that the Up / Down platform line is occupied.

A train from Forsinard booked to connect with a service to Thurso will be issued with a "Halkirk / Georgemas Occupied" token at Halkirk provided that no "Shunt" token has been issued at Georgemas, and the Up / Down platform line is clear throughout. The driver when being given permission to proceed, will be instructed to pass the stopping marker and to bring his train to a stand on Georgemas Down platform so as to be wholly on the Wick side of the stopping marker.

In the event of a failure of all cab equipment in the train from Halkirk, a special authority card may be issued provided that Clause (a) on the special authority card is endorsed "Loop Occ".

Splitting - Before uncoupling is carried out, the radio number of the rear train must be entered in the system.

A train must not be split unless each portion has at least one radio in working order.

"Halkirk/Georgemas Occupied" token - The Down direction "Halkirk / Georgemas Occupied" token must only be used for booked connecting of services on the Up / Down platform line at Georgemas, or for providing assistance to a train which has failed on the Up / Down platform line at Georgemas.

"Bower/ Georgemas Occupied" token - The Up direction "Bower/ Georgemas Occupied" token must only be used for booked joining of Sprinter trains, or booked connecting services on the Up / Down platform line at Georgemas, or for providing assistance to a train which has failed on the Up / Down platform line at Georgemas.

RETB Working by Pilotman - When RETB Working by Pilotman is in operation in the Georgemas area, the Pilotman must accompany any train proceeding to or from Wick or Thurso.

Working of pipe traffic - To facilitate the unloading of pipes on the Down main line between the station platform and the Down stop board (at the Wick end of the station) a COSS must be provided, in addition to the arrangements detailed in instruction 4.2 of the Single Lines Worked by Radio Electronic Token Block - Instructions to Traincrews, Persons carrying out Engineering Work and Others Concerned, who must authorise all movements of the pipe train (or portions of the pipe train) after this train has arrived at Georgemas Jn and the section token has been given up, until the whole train is ready to depart to Inverness and a section token has been issued.

Authority is granted for a RETB 'Engineering token' and/or 'Shunt token' to be issued as required to the COSS for the purpose of positioning and unloading, or shunting, this train, or portions of this train, as required.

The Engineering token and/or Shunt token must be given up when required for the purpose of passing passenger traffic through Georgemas Jn.

Whenever the pipe train, or a portion of the pipe train, requires to be propelled within the Georgemas Jn area, to position it for unloading or to shunt it clear of passenger traffic such movements must be carried out in accordance with the Rule Book, Module TW1, Section 13, except that all liaison by the guard/shunter, or driver, must be with the COSS, and not the signaller.

On each occasion when passenger traffic requires to pass, and after all unloading is complete, the COSS must ensure that the crane used for unloading is secured clear of the line and that all unloaded pipes have been positioned and secured for the safety of the train, before the Engineering and/or Shunt token is given up.

Dated: 02/12/06

SC203 - INVERNESS TO WICK

Bower TEP (Up direction only)

Drivers are exempt from carrying out the 'loop clear' procedure after passing Bower.

Dated: 02/12/06

SC203 - INVERNESS TO WICK

WICK TEP

Station Limits - Station Limits is defined as the line between the Station Limits board and the buffer stops.

Stabling of vehicles - One bogie vehicle fitted with a hand brake may be stabled in the Main road provided the hand brake is fully applied and the vehicle is scotched. A red flag during daylight and a red lamp during darkness or fog or falling snow must be exhibited on the Georgemas end of the vehicle so that it will be visible to the driver of an approaching train. Drivers approaching Wick must ensure that they have their train under such control as will enable them to stop short of any vehicle which may be standing in the Main road.

Dated: 02/12/06

SC203 - INVERNESS TO WICK

Entire Line Of Route

Automatic Warning System - Referring to the Rule Book, Module S3, Section 1.5, Cancelling indicators are not provided.

Special authority cards - Cancelled special authority cards referred to in clause 4.1 and 6.2 of the instructions Single Lines Worked by Radio Electronic Token Block - Instructions to Traincrews, Persons carrying out Engineering Work and Others Concerned must be left at the signing off point.

Level crossings - The person in charge of any Engineer's self-propelled On-Track machine or Road-Rail vehicle travelling over the above lines of route must ensure that the road warning lights at automatic level crossings are illuminated before proceeding over the crossing. If necessary, technical support to initiate the road traffic light sequence must accompany the machine / vehicle. Similarly, no automatic crossing must be left with a "stored failure" due to a machine / vehicle not operating the strike out track circuits / treadles. Technical support must be available to reset any crossing so affected.

SC205 - DINGWALL TO KYLE OF LOCHALSH

STRATHCARRON TEP To KYLE OF LOCHALSH TEP

Single line block section - The Down direction single line block section is defined as the line between the stop board at Strathcarron and the designated line buffer stop at Kyle of Lochalsh.

Dated: 02/12/06

SC205 - DINGWALL TO KYLE OF LOCHALSH

KYLE OF LOCHALSH TEP

Station Limits - Station Limits is defined as the line between the Station Limits board and the buffer stops.

Shunting - Drivers and others concerned, must exercise the utmost care when carrying out shunting operations at the pier at Kyle of Lochalsh. The locomotive must not be detached from the wagons or other vehicles when moving towards the pierhead until they have been brought to a stand and the hand brakes applied.

Dated: 02/12/06

SC205 - DINGWALL TO KYLE OF LOCHALSH

Entire Line Of Route

Automatic Warning System - Referring to the Rule Book, Module S3, Section 1.5, Cancelling indicators are not provided.

Special authority cards - Cancelled special authority cards referred to in clause 4.1 and 6.2 of the instructions Single Lines Worked by Radio Electronic Token Block - Instructions to Traincrews, Persons carrying out Engineering Work and Others Concerned must be left at the signing off point.

Level crossings - The person in charge of any Engineer's self-propelled On-Track machine or Road-Rail vehicle travelling over the above lines of route must ensure that the road warning lights at automatic level crossings are illuminated before proceeding over the crossing. If necessary, technical support to initiate the road traffic light sequence must accompany the machine / vehicle. Similarly, no automatic crossing must be left with a "stored failure" due to a machine / vehicle not operating the strike out track circuits / treadles. Technical support must be available to reset any crossing so affected.

SC207 - GEORGEMAS JN TO THURSO

Georgemas Jn To THURSO TEP

Single line block section - The Down direction single line block section is defined as the line between the Down branch stop board at Georgemas Jn and the designated line buffer stop at Thurso.

Single line "Long sections" - The Up direction single line "Long section" is defined as the line between the designated line Up stop board at Thurso and the Up / Down line Down stop board at Georgemas.

The Down direction single line "Long section" is defined as the line between the Up / Down platform line at Georgemas and the designated line buffer stop at Thurso.

Authority is given to issue / receive a Down direction "Long section" Georgemas / Thurso token while the train is at a stand on the Up / Down line at Georgemas station. The provisions of Single Lines Worked by Radio Electronic Token Block - Instructions to Traincrews, Persons carrying out Engineering Work and Others Concerned clause 3.1 are amended accordingly.

In the case of a "Long section" token, in either direction, the signaller will, when giving permission to proceed, specify to the driver that he is authorised to pass the Up or Down, as appropriate, branch stop board. The provisions of Single Lines Worked by Radio Electronic Token Block - Instructions to Traincrews, Persons carrying out Engineering Work and Others Concerned, clause 3.5 are amended accordingly. The provisions of clause 3.6 do not apply for a Thurso / Georgemas "Long section" token. For a Georgemas / Thurso "Long section" token the "intermediate token exchange point" is defined as the Down branch stop board for the purposes of this clause. For the purpose of clauses 3.7 and 5.1.2, the "intermediate token exchange point" is defined as the Up or Down, as appropriate, branch stop board at Georgemas Jn.

Up direction "Long section" tokens are **NOT** available for joining movements of Sprinter trains or for connecting services on the Up / Down platform line at Georgemas Jn.

Branch line stop boards - Movement of an Up direction train from Thurso beyond the Up branch stop board at Georgemas Jn must only be carried out with a "Shunt" token, except if a "Long section" token Thurso / Georgemas has been issued.

Movement of a Down direction train to Thurso towards the Down branch stop board at Georgemas Jn must only be carried out with a "Shunt" token, except if a "Long section" token Georgemas / Thurso has been issued.

Dated: 02/12/06

SC207 - GEORGEMAS JN TO THURSO

THURSO TEP

Station Limits - Station Limits is defined as the line between the Station Limits board and the buffer stops.

Dock line - The Dock line must not be used for passenger traffic.

Stabling of vehicles - One bogie vehicle fitted with a hand brake may be stabled in the Main line platform provided the hand brake is fully applied. A red flag during daylight and a red lamp during darkness or fog or falling snow must be exhibited on the Georgemas end of the vehicle so that it will be visible to the driver of an approaching train. Drivers approaching Thurso must ensure that they have their trains under such control as will enable them to stop short of any vehicle which may be standing in the Main line platform.

SC207 - GEORGEMAS JN TO THURSO

Entire Line Of Route

Automatic Warning System - Referring to the Rule Book, Module S3, Section 1.5, Cancelling indicators are not provided.

Special authority cards - Cancelled special authority cards referred to in clause 4.1 and 6.2 of the instructions Single Lines Worked by Radio Electronic Token Block - Instructions to Traincrews, Persons carrying out Engineering Work and Others Concerned must be left at the signing off point.

Level crossings - The person in charge of any Engineer's self-propelled On-Track machine or Road-Rail vehicle travelling over the above lines of route must ensure that the road warning lights at automatic level crossings are illuminated before proceeding over the crossing. If necessary, technical support to initiate the road traffic light sequence must accompany the machine / vehicle. Similarly, no automatic crossing must be left with a "stored failure" due to a machine / vehicle not operating the strike out track circuits / treadles. Technical support must be available to reset any crossing so affected.



This page is intentially blank